

OLIVER

Hesston

OLIVER

*Jobbing B-03
C-04*



OLIVER CORPORATION

COLUMBUS BRANCH

195 PHILLIPI ROAD • COLUMBUS, OHIO 43228

October 2, 1968

Dear Oliver Dealer:

On September 28, 1967 we made a mailing of a Hesston Cross-Reference. With the bean - corn harvest here we have had numerous requests for another copy of the cross reference. Attached you will find a duplication of this cross reference. Please file this with your Hesston Chopper parts book.

The Hesston part numbers are not listed in the price book or in the cross reference, or do we carry inventory control cards under the Hesston numbers. For this reason it is important you use the cross reference to place your order. As an example, an order comes in with the Hesston number 159483 spacer. This looks like a Charles City number. The girls peasting orders will look in the cross reference and find 159483AS - Charles City item which crosses over to 163117AS. Consequently you will likely receive the Charles City item instead of the Hesston part 7531170, and on other items you may receive your order and this item will be marked "Check Number". It is important to order these items under the Oliver number.

Your cooperation will be appreciated and if there are any questions pertaining to this, write us a letter.

Yours very truly,

OLIVER CORPORATION

R. H. Schwieterman
Repair Parts Manager

RHS:jjw
Attachment

FARM AND CONTRACTORS EQUIPMENT
"FOR MEN WHO GROW"



PARTS DEPOT BULLETIN



C-4158
PRINTED
U.S.A.

HESSTON CROSS-REFERENCE

HESSTON PART NUMBER	DESCRIPTION	LINE	OLIVER PART NUMBER
050344	BEARING	05	7530370
052118	RING	05	7530260
053538	IDLER	05	7530060
053561	IDLER	05	7530970
054510	IDLER	05	7530070
055277	V BELT	05	7530980
055657	BELT	05	7530950
055723	BELT	05	7530490
055731	V BELT	05	7530990
055749	V BELT	05	7531000
055772	V BELT	05	7531020
055822	BELT	05	7530080
055830	V BELT	05	7531010
055848	V BELT	05	7531030
055855	V BELT	05	7531040
056234	BELT	05	7531050
056259	V BELT	05	7531060
056606	V BELT	05	7531070
056630	V BELT	05	7531080
056978	V BELT	05	7531090
056986	BELT	05	7531100
061119	KEY	05	7530620
061416	KEY	05	7530630
063198	PIN	05	7531120
063982	PIN	05	7530390
065052	PIN	05	7531110
066043	BOLT	05	7531130
066050	BOLT	05	7531140
073015	CAPSCREW	05	7530890
074641	NUT	05	7530900
100610	SHEAVE	05	7530500
101519	BOLT	05	7531150
103010	IDLER	05	7530270
159384	IDLER	05	7531160
159459	SPACER	05	7530400
159483	SPACER	05	7531170
159517	SPACER	05	7530830
159541	SPACER	05	7530930
159558	SPACER	05	7531180
159624	SPACER	05	7530420
159640	SPACER	05	7530430
159665	SPACER	05	7532390
159889	SPACER	05	7530440
164269	FIN	05	7531190
164277	FIN	05	7531200
165050	PULLEY	05	7531210

HESSTON CROSS - REFERENCE

page 2

HESSTON PART NUMBER	DESCRIPTION	LINE	OLIVER PART NUMBER
165167	PANEL	05	7531220
165191	PULLEY	05	7531230
165258	ANGLE	05	7531240
165324	SPACER	05	7530450
165357	SPACER	05	7531250
165589	BAFFLE	05	7531260
166629	PULLEY	05	7531270
166751	HAMMERS	05	7531280
166769	SPACERS	05	7531290
166777	PANEL	05	7531300
167320	PULLEY	05	7531310
167429	HAMMERS	05	7531320
167536	SHAFT	05	7531330
167726	PULLEY	05	7531340
167734	HAMMERS	05	7531350
167775	CONCAVE	05	7531360
167999	HAMMERS	05	7531370
168591	SPACERS	05	7531380
169383	PANEL	05	7531390
170332	FIN	05	7531400
170340	FIN	05	7531410
171538	ROTOR	05	7531420
171603	SHAFT	05	7531430
171785	ROTOR ASSY	05	7531440
171793	ROTOR ASSY	05	7531450
172296	SHEAVE	05	7531460
172320	SHEAVE	05	7530280
172403	SHEAVE	05	7531470
172890	HAMMERS	05	7531480
172916	HAMMERS	05	7531490
172924	HAMMERS	05	7531500
173211	HOUSING	05	7531510
173336	FIN	05	7531520
173344	FIN	05	7531530
185397	PANEL	05	7531540
185413	ANGLE	05	7531550
185421	ANGLE	05	7531560
185439	ANGLE	05	7531570
185447	ANGLE	05	7531580
185496	SUPPORT	05	7531590
185520	SHEAVE	05	7531600
185645	SHEAVE	05	7531610
187880	BRACKET	05	7531620
188227	SHEAVE	05	7531630
199539	BRACKET	05	7531640
199554	STRAP	05	7531650
199562	MOUNTING	05	7531660
199588	BRACKET	05	7531670
199596	BRACKET	05	7531680
199612	SHIELD	05	7531690
199810	BRACKET	05	7531700
199877	SHEAVE	05	7531710
199885	J BOLT	05	7531720

HESSTON CROSS - REFERENCE

page 3

HESSTON PART NUMBER	DESCRIPTION	LINE	OLIVER PART NUMBER
200105	EXTENSION	05	7531730
200147	PULLEY	05	7531740
208116	SHEAVE	05	7531750
208124	HUB	05	7531760
212555	FLANGE	05	7530290
212712	CLIP	05	7531770
212936	CONCAVE	05	7531780
214262	CONCAVE	05	7531790
214437	BRACKET	05	7531800
217349	CONCAVE	05	7531810
217893	CONCAVE	05	7531830
218057	PANEL	05	7531840
218396	SHEAVE	05	7531850
218818	MOUNTING	05	7531860
218834	CHUTE	05	7531870
218842	CHUTE	05	7531880
218974	BRACKET	05	7531890
219105	CLAMP	05	7531900
219113	MOUNTING	05	7531910
219121	MOUNTING	05	7531920
219139	CHUTE	05	7531930
219964	SHEAVE	05	7531940
219972	PANEL	05	7531950
219980	KEY	05	7531960
221416	BOLT	05	7530670
222844	BRACKET	05	7531970
231860	BRACKET	05	7531980
232165	ASSY	05	7531820
236653	SHEAVE	05	7531990
244467	HOUSING	05	7532000
244527	HOUSING	05	7532010
244640	PANEL	05	7532020
244814	SPREADER	05	7532030
244889	SPREADER	05	7532050
245084	BUSHING	05	7530480
245134	FIN	05	7530090
245142	FIN	05	7530100
245639	HAMMERS	05	7532060
245654	HAMMERS	05	7532070
245670	HAMMERS	05	7532080
245688	HAMMERS	05	7532090
245845	CONCAVE	05	7532100
251892	PANEL	05	7532110
251918	PANEL	05	7532120
251926	PANEL	05	7532130
251934	PANEL	05	7532140
251942	MOUNTING	05	7530110
252015	SHEAVE	05	7532150
252023	SHEAVE	05	7532160
252031	SHEAVE	05	7530120
252049	CHUTE	05	7532170
252056	BRACKET	05	7530130
252072	BOLT	05	7530460

HESSTON CROSS - REFERENCE

page 4

HESSTON PART NUMBER	DESCRIPTION	LINE	OLIVER PART NUMBER
252544	CLIP	05	7532190
252551	BRACKET	05	7532200
257949	LINK	05	7532210
257972	BRACKET	05	7532220
258004	BRACKET	05	7532230
258012	LINK	05	7532240
258020	MOUNTING	05	7532250
258038	ANGLE	05	7532260
258046	CHUTE	05	7532270
258079	CHUTE	05	7532280
271692	BRACE	05	7530140
271783	CHUTE	05	7532290
271809	PANEL	05	7532300
271858	CHUTE	05	7532310
271924	SHEAVE	05	7532320
275388	SHEAVE	05	7530150
275396	SHEAVE	05	7532330
275404	BELTS	05	7530170
275420	BRACKET	05	7530180
277434	BELTS	05	7530250
295733	RAIL	05	7530300
301499	MOUNTING	05	7532340
301507	MOUNTING	05	7532350
302919	RAIL	05	7530310
303917	PANEL	05	7530640
303925	PANEL	05	7530200
303933	PANEL	05	7530210
303941	CHUTE	05	7532360
303974	CHUTE	05	7530510
304022	SHEAVE	05	7530520
304048	SHAFT	05	7530530
306225	BRACE	05	7530540
321448	ROTOR	05	7530810
321521	ROTOR	05	7530770
321554	ROTOR	05	7530790
321745	PANEL	05	7530320
321786	PANEL	05	7530740
321885	BOARD	05	7530220
321919	SPREADER	05	7532040
321935	BOARD	05	7530700
321968	BOARD	05	7530550
323766	HAMMER SET	05	7530780
323782	HAMMER SET	05	7530820
323816	HAMMER SET	05	7530800
323873	CHUTE	05	7530710
323931	CHUTE	05	7530230
333500	SHEAVE	05	7530560
333823	IDLER ASSY	05	7532370
336412	BOLT	05	7530470
336578	SHAFT	05	7530720
336586	BRACKET	05	7530570
336594	BRACKET	05	7530580
393405	HOUSING	05	7530650

HESSTON CROSS - REFERENCE

PAGE 5

HESSTON PART NUMBER	DESCRIPTION	LINE	OLIVER PART NUMBER
393439	HOUSING	05	7530750
393488	HOUSING	05	7530330
393744	BRACKET	05	7530340
393751	PIN	05	7530350
393777	CONCAVE	05	7530610
393801	CONCAVE	05	7530760
393843	CONCAVE	05	7530360
398842	BRACKET	05	7530590
398867	CHUTE	05	7530680
398891	CHUTE	05	7530240
398933	CHUTE	05	7530730
411066	BRACE	05	7530920
411165	BRACKET	05	7530870
411207	ARM	05	7530840
411231	BRACKET	05	7530850
411249	BOLT	05	7530860
413807	SHEAVE	05	7530960
413815	SHEAVE	05	7530940
413823	SHEAVE	05	7530160
701169	SCREW	05	7530880
702027	CAPSCREW	05	7530910
710004	BEARING	05	7532380
710012	BEARING	05	7530680