



1. Headlamps-2. Batteries-3. Alternator-4. Sending Unit - Water Temp. -5. Horn-6. Sending Unit - Oil Pressure-7. Relay - Battery Charge-8. Voltage Regulator-9. Fusebox-10. Thermostarter-11. Starter-12. Voltage Regulator Fuse-13. Sending Unit - Fuel Gauge-14. Battery Charge Indicator-15. Indicator -

Lights-16. Fuel/Water Temp. Gauge-17. Indicator - Oil Pressure-18. Switch - Starter/Thermostarter-19. Switch - Safety Starting-20. Switch - Lock-21. Switch - Horn-22. Taillamp-24. Rear Floodlamp-25. Taillamp-26. Flashing Unit-27. Warning Light

COLOR CODE:

M - Brown	A - Light blue	B - White	G - Yellow	H - Grey	L - Blue
AN - Light blue-Black	N - Black	R - Red	S - Pink	V - Green	Z - Violet
	GN - Yellow-Black	HN - Grey-Black	HR - Grey-Red	VN - Green-Black	