



Figure 4-14 Super 66, 77, 88 Diesel 12-Volt Wiring Diagram (Starter Rod)