



Figure 4-13 Super 77, 88 HC And LPG 12-Volt Wiring Diagram (Key Starter)